
















	Artikel	Inhalt volume Größe size	Art.-Nr.
	<b>Kaffeekanne</b> coffeepot cafetière caffettiera cafetera	0,33 l	4010
	<b>Teekanne</b> teapot théière teiera tetera	0,40 l	4210
	<b>Gießer mit Henkel</b> creamer with handle crémier avec anse lattiera c. man. lechera c. asa	0,15 l	4415
	<b>Zuckerdose</b> sugar bowl sucrier zuccheriera azucarero	0,25 l	4330
	<b>Tasse hoch/Espresso</b> cup and saucer tasse et soucoupe tazza con piatto taza con platito	0,09 l	Obere 4712
			Untere 4711
	<b>Tasse niedrig</b> cup and saucer low tasse et souc. basse tazza bassa con piatto taza baja con platito	0,18 l	Obere 4742
			Untere 4731
	<b>Trinkbecher **</b> mug tasse bicchiere taza	0,30 l	4882
	<b>Suppentasse</b> creamsoup c/s stackable tasse à bouillon et souc. tazza da brodo taza de sopa	0,30 l	Obere 0422
			Untere 4731
	<b>Teller flach</b> plate flat assiette plate piatto piano plato plano	17 cm	0017
		20 cm	0020
		23,5 cm	0024
		27 cm	0027
		30 cm	0030
	<b>Teller tief</b> plate deep assiette creuse piatto fondo plato hondo	23 cm	0123
	<b>Platte oval</b> platter oval plat ovale piatto ovale fuente esquinada	23 cm	2623
		32 cm	2632
		37 cm	2637
	<b>Dessertschale</b> fruit dish compotier compostiera compotera	13 cm	0513
	<b>Salats rund</b> salad bowl saladier insalatiera ensaladera	16 cm	0616
		21 cm	0621
	<b>Ragoufinschale**</b> bowl bol ragout-fin ciotola per ragù fin plato legumbrera	0460	
	<b>Eierbecher**</b> egg cup coquetier portauovo huevera	13 cm	1836

• **Kombi-Untere**

\* passend für:  
Tasse niedrig 0,18 l  
Suppentasse 0,30 l

\*\* ohne Relief