
























Artikel	Inhalt volume Größe size	Art.-Nr.
 Kaffeekanne coffeepot cafetière caffettiera cafetera	0,30	4010
 Teekanne teapot théière teiera tetera	0,40 l	4210
 Gießer ohne Henkel creamer without handle crémier sans anse lattiera senza man. lechera sin asa	0,04 l	4404
 Gießer mit Henkel creamer with handle crémier avec anse lattiera c. man. lechera c. asa	0,15 l 0,30 l	4415 4430
 Zuckerschale sugar dish coupe à sucre piattino p. zucchero platito para azucar	8 cm	4360
 Zuckerdose sugar bowl sucrier zuccheriera azucarero	0,25 l	4330
 Tasse hoch/Espresso cup and saucer tall tasse et soucoupe haute tazza alta con piatto taza alta con platito	0,10 l Obere Untere	4712 4711
 Tasse hoch cup and saucer tall tasse et soucoupe haute tazza alta con piatto taza alta con platito	0,15 l Obere Untere	4722 4721
 Tasse niedrig cup and saucer low stack. tasse et soucoupe basse tazza bassa con piatto taza baja con platito	0,18 l Obere Untere	4742 4731
 Tasse hoch cup and saucer tall tasse et soucoupe haute tazza alta con piatto taza alta con platito	0,20 l Obere Untere	4732 4731
 Tasse nicht stapelbar cup and saucer tasse et soucoupe tazza con piatto taza con platito	0,22 l Obere Untere	4642 4731
 Tasse hoch cup and saucer tall tasse et soucoupe haute tazza alta con piatto taza alta con platito	0,28 l Obere Untere	4762 4731
 Trinkbecher stapelbar mug stackable tasse bicchiere taza	0,26 l Untere	4882 4731
 Teller flach plate flat assiette plate piatto piano plato llano	17 cm 19 cm 21 cm 25 cm 28 cm 30 cm 23 cm	0017 0019 0021 0025 0028 0030 0023

Artikel	Inhalt volume Größe size	Art.-Nr.
 Teller tief Coup coup plate deep assiette creuse coupe piatto fondo coup plato hondo coup	19 cm	0119
 Teller tief Fahne plate deep with rim assiette creuse piatto fondo plato hondo	22 cm	0122
 Suppentasse creamsoup stack. tasse à bouillon et souc. tazza da brodo taza de sopa	0,26 l Obere Untere	0422 0421 4731
 Bowl stapelbar bowl stackable bol bowl frutero	0,26 l	0510
 Platte oval platter oval plat ovale piatto ovale fuente esquinada	25 cm 28 cm 32 cm 36 cm	2625 2628 2632 2636
 Salats rund salad bowl saladier insalatiera ensaladera	14 cm 17 cm 21 cm 23 cm	0614 0617 0621 0623
 Kompott fruit dish compotier compostiera compotera	13 cm	0513
 Sauciere komplett gravyboat saucière salsiera salsera	0,35 l Oberteil Unterteil (=Teller flach 17 cm)	1622 0617
 Buttersauciere butterboat saucière à beurre salsiera per burro salsera de mantequilla	0,10 l	1830
 Ascher flach ashtray cendrier posacenere cenicero	16 cm 11 cm	5606 5603
 Eierbecher egg cup coquetier portauovo huevera		1836
 Butternapf butterdish cuppelle a beurre portaburro mantequillera	7 cm	2909
 Ascher ashtray cendrier posacenere cenicero	9 cm	5600
 Salzstreuer salt shaker salière spargi sale salero		1800
 Pfefferstreuer pepper shaker poivrière spargi pepe pimentero		1804

Artikel	Inhalt volume Größe size	Art.-Nr.
Universalartikel (ohne Relief)		
 Teller flach plate flat assiette plate piatto piano plato llano	30 cm	0030
 Pastateller tief pasta bowl assiette coupe piatto coup plato coup	27 cm	0127
 Vase vase vase vaso florero	10 cm	6110
 Leuchter candle stick chandelier candeliera candelabro		5705
 Ascher hoch stapelbar ashtray cendrier posacenere cenicero	9 cm	5600
 Zigarrenascher eckig ashtray cendrier posacenere cenicero		5600
 Salzstreuer salt shaker salière spargi sale salero		9410
 Pfefferstreuer pepper shaker poivrière spargi pepe pimentero		9411

• **Kombi-Untere**

* passend für: Tasse niedrig 0,18 l
Tasse hoch 0,20 l; 0,28 l
Tasse nicht stapelbar 0,22 l
Trinkbecher 0,26 l
Suppentasse 0,26 l