


































Artikel	Inhalt volume Größe size	Art.-Nr.
 Kaffeekanne coffeepot cafetière caffettiera cafetera	0,30 l	4010
 Teekanne teapot théière théière tetera	0,40 l	4210
 Gießer ohne Henkel creamer without handle crémier sans anse lattiera senza man. lechera sin asa	0,03 l	4403
 Gießer mit Henkel creamer with handle crémier avec sanse lattiera c. man. lechera c. asa	0,15 l 0,30 l	4415 4430
 Zuckerdose sugar bowl sucrier zuccheriera azucarero	0,25 l	4330
 Zuckerschale sugar dish coupe à sucre piattino p. zucchero platito para azucar	8 cm	4360
 Tasse hoch/Espresso cup and saucer tall tasse et soucoupe haute tazza alta con piatto taza alta con platito	0,09 l Obere Untere	4712 4711
 Tasse niedrig cup and saucer low stack. tasse et soucoupe basse tazza bassa con piatto taza baja con platito	0,18 l Obere Untere	4742 4751
 Tasse hoch cup and saucer tall tasse et soucoupe haute tazza alta con piatto taza alta con platito	0,20 l Obere Untere	4732 4751
 Tasse hoch/konisch cup and saucer tall tasse et soucoupe haute tazza alta con piatto taza alta con platito	0,23 l Obere Untere	4749 4751
 Tasse hoch cup and saucer tall tasse et soucoupe haute tazza alta con piatto taza alta con platito	0,26 l Obere Untere	4752 4751
 Trinkbecher mug stack. tasse bicchiere taza	0,26 l	4882
 Teller flach plate flat assiette plate piatto piano plato llano	16 cm 20 cm 26 cm 28 cm 31 cm 23 cm	0016 0020 0026 0028 0031 0023

Artikel	Inhalt volume Größe size	Art.-Nr.
 Teller tief Fahne plate deep assiette creuse piatto fondo plato hondo	22 cm	0122
 Teller tief coup plate flat with small rim assiette plate à bord étroite piatto piano bordo stretto plato llano borde angosto	19,5 cm	0120
 Suppentasse stapelbar creamsoup stack. tasse à bouillon et souc. tazza da brodo taza de sopa	0,26 l Obere Untere	0422 4751
 Bowl stapelbar bowl stack. bol bowl frutero	0,26 l	0513
 Platte oval platter oval plat ovale piatto ovale fuente esquinada	24 cm 29 cm 32 cm 36 cm	2624 2629 2632 2636
 Salats rund salad bowl saladier insalatiera ensaladera	15 cm 18 cm 21 cm 23 cm	0615 0618 0621 0623
 Sauciere komplett gravyboat saucière salsiera (=Teller flach 16 cm) salsiera	0,30 l Oberteil Unterteil	1622 0016
 Buttersauciere** butterboat saucière à beurre salsiera per burro salsiera de mantequilla	0,10 l	1830
 Ascher ashtray cendrier posacenere cenicero	15 cm	5601
 Eierbecher** egg cup coquetier portauovo huevera	13 cm	1836
 Butternapf** butterdish small coupelle a beurre petit portaburro piccolo mantequillera pequeña	8,5 cm	2910

Artikel	Inhalt volume Größe size	Art.-Nr.
 Universalteller (ohne Relief)	30 cm	0030
 Teller flach plate flat assiette plate piatto piano plato llano	30 cm	0030
 Pastateller tief pasta bowl assiette coupe piatto coup plato coup	27 cm	0127
 Vase vase vase vaso florero	10 cm	6110
 Leuchter candle stick chandelièr candelieri candelabro		5705
 Ascher hoch stapelbar ashtray cendrier posacenere cenicero	9 cm	5600
 Zigarrenascher eckig ashtray cendrier posacenere cenicero		5600
 Salzstreuer salt shaker salière spargi sale salero		9410
 Pfefferstreuer pepper shaker poivrière spargi pepe pimentero		9411

*** Kombi-Untere**

* passend für: Tasse niedrig 0,18 l
Tasse hoch 0,20 l; 0,26 l
Tasse hoch/konisch 0,23 l;
Suppentasse 0,26 l

**** ohne Relief**