



dua



	Artikel	Inhalt volume Größe size	Art.-Nr.
	Kaffeekanne coffeepot cafetière caffettiera cafetera	0,33 l	4010
	Teekanne teapot théière teiera tetera	0,40 l	4210
	Gießer mit Henkel creamer with handle crémier avec anse lattiera c. man. lechera c. asa	0,15 l	4415
	Zuckerdose sugar bowl sucrier zuccheriera azucarero	0,25 l	4330
	Tasse hoch/Espresso cup and saucer tasse et soucoupe tazza con piatto taza con platito	0,09 l Obere Untere	4712 4711
	Tasse niedrig cup and saucer low tasse et souc. basse tazza bassa con piatto taza baja con platito	0,18 l Obere Untere	4742 4731
	Trinkbecher ** mug tasse bicchiere taza	0,30 l	4882
	Suppentasse creamsoup c/s stackable tasse à bouillon et souc. tazza da brodo taza de sopa	0,30 l Obere Untere	0422 4731
	Teller flach plate flat assiette plate piatto piano plato plano	17 cm 20 cm 23,5 cm 27 cm 30 cm	0017 0020 0024 0027 0030
	Teller tief plate deep assiette creuse piatto fondo plato hondo	23 cm	0123
	Platte oval platter oval plat ovale piatto ovale fuente esquinada	23 cm 32 cm 37 cm	2623 2632 2637
	Dessertschale fruit dish compotier compostiera compotera	13 cm	0513
	Salats rund salad bowl saladier insalatiera ensaladera	16 cm 21 cm	0616 0621
	Ragoufinschale** bowl bol ragout-fin ciotola per ragù fin plato legumbrera		0460
	Eierbecher** egg cup coquetier portauovo huevera	13 cm	1836

▪ **Kombi-Untere**

* passend für:
Tasse niedrig 0,18 l
Suppentasse 0,30 l

** ohne Relief